WM-D6C/TC-D6C

SONY

SERVICE MANUAL

US Model
WM-D6C/TC-D6C
Canadian Model
AEP Model
UK Model
E Model
WM-D6C

SUPPLEMENT-3

File this supplement with the service manual.

Subject: French model addition (WM-D6C)

(ECN-WM801529)

- **French Model Addition**
  French model is almost the same as AEP model.
  As only the difference from AEP model is described in this manual, please refer to WM-D6C/TC-D6C service manual (9-951-385-□□) previously issued for other information

- **Difference Table**

Page	AEP Model						French Model					
	Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
(14)	*	A-3060-812-A	MAIN BOARD, COMPLETE **********					A-3021-241-A	MAIN BOARD, COMPLETE **********			
	R152	1-216-005-00	METAL CHIP	15	5%	1/10W	R152	1-216-042-00	METAL CHIP	510	5%	1/10W
	R252	1-216-005-00	METAL CHIP	15	5%	1/10W	R252	1-216-042-00	METAL CHIP	510	5%	1/10W

NOTE:
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- Page in ( ) indicates the page in Service Manual Supplement-2.

MEMO